

Mounting material:

- 4x M6x60 anchor bolts



Assembly:

- Use the assembly material provided for assembly.
- Mark the drill holes. Drill the holes $\Phi 10\text{mm}$ depth about 55mm.
- Disassemble the anchor bolts into the individual components by unscrewing the threaded cap mounted on the underside.
- First insert the threaded cap (1) into the cylinder (2) (pay attention to the alignment).
- Sink the 4 prepared cylinders with the cap into the holes.
- Open the door and fasten the parcel box using the screws (4) and the washers (3).
- It can be wall or floor mounted according to your needs. For wall mounting, open the slot flap.

